

GENERAL DESCRIPTION

The isolated converter DAT1135 is able to execute many functions such as: measure and linearisation of the temperature characteristic of RTDs sensors, conversion of a linear resistance variation, conversion of a voltage signal even coming from a potentiometer connected on its input. The DAT1135 is able to measure and linearise the standard thermocouples with internal cold junction compensation. The measured values are converted in a 0+10 V signal. The device guarantees high accuracy and performance stability both in time and in temperature. The programming of the DAT1135 is made by a Personal Computer using the software DATESOFT and the cable CVPROG, both developed and provided by DATEXEL. By DATESOFT, that runs under the operative system "WindowsTM", it is possible to configure the transmitter to interface it with the most used sensors.

For Resistance and RTDs sensors it is possible to program the cable compensation with 3 or 4 wires; for Thermocouples it is possible to program the Cold Junction Compensation (CJC) as internal or external.

It is possible to set the minimum and maximum values of input and output ranges in any point of the scale, keeping the minimum span shown in the table below

It is available the option of alarm for signal interruption (burn-out) that allows to set the output value as high or low out of scale On the device is provided a function that allows the user to set a programmable filter up to 30 seconds to reduce eventual sudden variations of the input signal

The 1500 Vac isolation between input and power supply/output eliminates the effects of all ground loops eventually existing and allows the use of the converter in heavy environmental conditions found in industrial applications.

It is housed in a self-extinguish plastic enclosure suitable for DIN B in-head mounting.

Moreover (by proper mounting kit) it is possible to mount the DAT1135 on DIN rail.

USER INSTRUCTIONS

The converter DAT1135 must be powered by a direct voltage from 18 up to 30V applied to the terminals +V and -V.

The output signal 0+10 V is measurable between the terminals O(OUT) and -V.

The input connections must be made as shown in the section "Input connections".

To configure, calibrate and install the converter refer to sections "DAT1135: configuration and calibration" and "Installation Instructions".

TECHNICAL SPECIFICATIONS (Typical at 25 °C and in nominal conditions)

Input type	Min	Мах	Min. span	Input calibration (1)		Output Load resistance – Rload		
TC(*) CJC int./ext.				RTD Low res.	> of ±0.1% f.s. or ±0.2°C > of ±0.1% f.s. or ±0.15 Ω	Voltage output Short-circuit current	≥ 5 KΩ 26 mA max	
J K S	-200°C -200°C 0°C	1200°C 1300°C 1750°C	100°C 100°C 400°C	High res. mV, TC	> of ±0.2% f.s. or ±1 Ω > of ±0.1% f.s. or ±10 uV	Response time (10÷ 90%)	about 200 ms	
R B E	0°C 0°C -200°C	1750°C 1800°C 1000°C	400°C 400°C 100°C	Output calibration Voltage ± 5 mV		Output filter programmability Selectable from 0.2 to 30 s.		
T N	-200°C -200°C	400°C 1300°C	100°C 100°C	Input impedance TC, mV Linearity (1)	>= 10 MΩ	Power supply Power supply voltage 18 30 Vdc		
		850°C 185°C	50°C 30°C	TC RTD	± 0.2 % f.s. ± 0.1 % f.s.	Current consumption Reverse polarity protectio	10 mA max. 60 Vdc max	
Ni100 Ni100	-200°C -60°C -60°C	180°C 180°C 150°C	50°C 30°C	Line resistance influenceTC, mV<=0.8 uV/Ohm		Isolation voltage Input – Pow. supply/Output 1500 Vac, 50 Hz,1min		
Voltage mV mV mV	-100mV -100mV -100mV	+90mV +200mV +800mV	5 mV 10 mV 20 mV	RTD 4 wires $0.005\%/\Omega$ (100 Ω balanced max.) RTD excitation current Typical 0.350 mA CJC comp. $\pm 0.5^{\circ}$ C		Temperature & humidity Operative temperature Storage temperature Humidity (not condensed)	-40°C +85°C -40°C +85°C	
Potentiometer (R nom. < 50 KΩ)	0%	100%	5%	Thermal drift (1) Full scale CJC	± 0.01% / °C ± 0.01% / °C	Housing Material PC +	C + ABS V0 IN B head or bigger	
RES. 2,3,4 wires	0Ω 0Ω	500 Ω 2000 Ω	50 Ω 500 Ω	Burn-out values Max. Fault value Min. Fault value	about 11.1 V about -0.65 V	EMC (for industrial envi	3 mm ; H = 24 mm ronments)	
Output type	Min	Мах	Min. span			Immunity EN 61 Emission EN 61)0-6-2)0-6-4	
Direct voltage Reverse voltage	0 V 10 V	10 V 0 V	1 V 1 V					
				(1) referred to input Span	n (difference between max. and min. values)			

(*) For temperature sensors it is possible to set the input range also in F degrees; to made the conversion use the formula: °F = (°C*9/5)+32)

DAT 1135: CONFIGURATION

Notice: before to execute the next operations, check that the drivers of the cable CVPROG in use have been previously installed in the Personal Computer.

- 1) Remove the protection plastic cap on DAT1135.
- 2) Connect the two plugs of cable CVPROG to the Personal Computer (USB plug) and to the device (uUSB plug) .
- Run the software DATESOFT. Set the COM port assigned to the CVPROG cable by the Operative System.
- 4) Set the parameters of configuration .
- 5) Program the device.

- CALIBRATION CONTROL


With software DATESOFT running and device powered:

1) Connect on the input a calibrator setted with minimum and maximum values referred to the electric signal or to the temperature sensor to measure.


2) Set the calibrator at the minimum value.

- 3) Verify that the device provides on output the minimum set value.
- 4) Set the calibrator at the maximum value.
- 5) Verify that the device provides on output the maximum set value.


CONFIGURATION BY CABLE CVPROG



DIN B in-head mounting



MECHANICAL DIMENSIONS (mm)





The symbol reported on the product indicates that the product itself must not be considered as a domestic waste.


It must be brought to the authorized recycle plant for the recycling of electrical and electronic waste. For more information contact the proper office in the user's city , the service for the waste treatment or the

supplier from which the product has been purchased.


INSTALLATION INSTRUCTIONS

The device DAT1135 is suitable for direct DIN B in-head mounting. The converter must be fixed inside the probe by the proper kit. By apposite stirrup, provided on request, it is possible to mount the device on DIN rail in compliance with EN-50022. It is necessary to install the device in a place without vibrations; avoid to routing conductors near power signal cables .


DIN rail mounting (DIN RAIL Option)




DAT1135 CONNECTIONS




POWER SUPPLY CONNECTIONS



Terminal -V = GND POWER SUPPLY OUTPUT CONNECTIONS



Terminal -V = GND OUTPUT



HOW TO ORDER

The DAT1135 is provided as requested on the Customer's order. Refer to the section "Technical specification" to determine input and output ranges. <u>The mounting kit for DIN rail is provided **only on request** with code DIN RAIL. In case of the configuration is not specified, the parameters must be set by the user.</u>

ORDER CODE EXAMPLE:

DAT1135 / Pt10	00/3 w	ires/0 ÷ 2	00 °C /	0 ÷ 10) V /	Burn-out up					
Input type						High or low Out of scale					
Sensor options : RTD/RES:2,3,4 wires						Output range					
TC: CJC int. or ext.		Input ra	nge								